Installing Synchronous Link Modules in BN Platforms

Part No. 114944-A Rev. A
January 1997

Bay Networks

Bay Networks

4401 Great America Parkway
Santa Clara, CA 95054

8 Federal Street
Billerica, MA 01821

Copyright © 1988–1997 Bay Networks, Inc.

All rights reserved. Printed in the USA. January 1997.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Bay Networks, Inc.

The software described in this document is furnished under a license agreement and may only be used in accordance with the terms of that license. A summary of the Software License is included in this document.

Restricted Rights Legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notice for All Other Executive Agencies

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Trademarks of Bay Networks, Inc.

ACE, AFN, AN, BCN, BLN, BN, BNX, CN, FN, FRE, GAME, LN, Optivity, PPX, SynOptics, SynOptics Communications, Wellfleet and the Wellfleet logo are registered trademarks and ANH, ASN, Bay•SIS, BayStack, BCNX, BLNX, EZ Install, EZ Internetwork, EZ LAN, PathMan, PhonePlus, Quick2Config, RouterMan, SPEX, Bay Networks, Bay Networks Press, the Bay Networks logo and the SynOptics logo are trademarks of Bay Networks, Inc.

Third-Party Trademarks

All other trademarks and registered trademarks are the property of their respective owners.

Statement of Conditions

In the interest of improving internal design, operational function, and/or reliability, Bay Networks, Inc. reserves the right to make changes to the products described in this document without notice.

Bay Networks, Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product are Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

Electromagnetic Emissions

Meets requirements of:

FCC Part 15, Class A
EN 55 022 (CISPR 22:1985), Class A <and Class B>
VCCI Class 1 ITE

Canada Requirements Only

Canada CS-03 Rules and Regulations

Note: The Canadian Department of Communications label identifies certified equipment. The certification means that the equipment meets certain telecommunications network protective operations and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent the degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

Canada CS-03 -- Règles et règlements

Note: L’étiquette du ministère des Communications du Canada indique que l’appareillage est certifié, c’est-à-dire qu’il respecte certaines exigences de sécurité et de fonctionnement visant les réseaux de télécommunications. Le ministère ne garantit pas que l’appareillage fonctionnera à la satisfaction de l’utilisateur.

Avant d’installer l’appareillage, s’assurer qu’il peut être branché aux installations du service de télécommunications local. L’appareillage doit aussi être raccordé selon des méthodes acceptées. Dans certains cas, le câblage interne du service de télécommunications utilisé pour une ligne individuelle peut être allongé au moyen d’un connecteur certifié (prolongateur téléphonique). Le client doit toutefois prendre note qu’une telle installation n’assure pas un service parfait en tout temps.

Les réparations de l’appareillage certifié devraient être confiées à un service d’entretien canadien désigné par le fournisseur. En cas de réparation ou de modification effectuées par l’utilisateur ou de mauvais fonctionnement de l’appareillage, le service de télécommunications peut demander le débranchment de l’appareillage.

Pour leur propre sécurité, les utilisateurs devraient s’assurer que les mises à la terre des lignes de distribution d’électricité, des lignes téléphoniques et de la tuyauterie métallique interne sont raccordées ensemble. Cette mesure de sécurité est particulièrement importante en milieu rural.

Attention: Les utilisateurs ne doivent pas procéder à ces raccordements eux-mêmes mais doivent plutôt faire appel aux pouvoirs de réglementation en cause ou à un électricien, selon le cas.

Canada Requirements Only *(continued)*

D. O. C. Explanatory Notes: Equipment Attachment Limitations

The Canadian Department of Communications label identifies certified equipment. This certification meets certain telecommunication network protective, operational and safety requirements. The department does not guarantee the equipment will operate to the users satisfaction.

Before installing the equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above condition may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electrical inspection authority, or electrician, as appropriate.

Notes explicatives du ministère des Communications: limites visant les accessoires

L'étiquette du ministère des Communications du Canada indique que l'appareillage est certifié, c'est-à-dire qu'il respecte certaines exigences de sécurité et de fonctionnement visant les réseaux de télécommunications. Le ministère ne garantit pas que l'appareillage fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer l'appareillage, s'assurer qu'il peut être branché aux installations du service de télécommunications local. L'appareillage doit aussi être raccordé selon des méthodes acceptées. Dans certains cas, le câblage interne du service de télécommunications utilisé pour une ligne individuelle peut être allongé au moyen d'un connecteur certifié (prolongateur téléphonique). Le client doit toutefois prendre note qu'une telle installation n'assure pas un service parfait en tout temps.

Les réparations de l'appareillage certifié devraient être confiées à un service d'entretien canadien désigné par le fournisseur. En cas de réparation ou de modification effectuées par l'utilisateur ou de mauvais fonctionnement de l'appareillage, le service de télécommunications peut demander le débranchment de l'appareillage.

Pour leur propre sécurité, les utilisateurs devraient s'assurer que les mises à la terre des lignes de distribution d'électricité, des lignes téléphoniques et de la tuyauterie métallique interne sont raccordées ensemble. Cette mesure de sécurité est particulièrement importante en milieu rural.

Attention: Les utilisateurs ne doivent pas procéder à ces raccordements eux-mêmes mais doivent plutôt faire appel aux pouvoirs de réglementation en cause ou à un électricien, selon le cas.

Canada Requirements Only *(continued)*

Canadian Department of Communications Radio Interference Regulations

This digital apparatus (Access Feeder Node, Access Link Node, Access Node, Access Stack Node, Backbone Concentrator Node, Backbone Concentrator Node Switch, Backbone Link Node, Backbone Link Node Switch, Concentrator Node, Feeder Node, Link Node) does not exceed the Class A limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Réglement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique (Access Feeder Node, Access Link Node, Access Node, Access Stack Node, Backbone Concentrator Node, Backbone Concentrator Node Switch, Backbone Link Node, Backbone Link Node Switch, Concentrator Node, Feeder Node, Link Node) respecte les limites de bruits radioélectriques visant les appareils numériques de classe A prescrites dans le Réglement sur le brouillage radioélectrique du ministère des Communications du Canada.

Bay Networks Software License

Note: This is Bay Networks basic license document. In the absence of a software license agreement specifying varying terms, this license -- or the license included with the particular product -- shall govern licensee's use of Bay Networks software.

This Software License shall govern the licensing of all software provided to licensee by Bay Networks ("Software"). Bay Networks will provide licensee with Software in machine-readable form and related documentation ("Documentation"). The Software provided under this license is proprietary to Bay Networks and to third parties from whom Bay Networks has acquired license rights. Bay Networks will not grant any Software license whatsoever, either explicitly or implicitly, except by acceptance of an order for either Software or for a Bay Networks product ("Equipment") that is packaged with Software. Each such license is subject to the following restrictions:

1. Upon delivery of the Software, Bay Networks grants to licensee a personal, nontransferable, nonexclusive license to use the Software with the Equipment with which or for which it was originally acquired, including use at any of licensee's facilities to which the Equipment may be transferred, for the useful life of the Equipment unless earlier terminated by default or cancellation. Use of the Software shall be limited to such Equipment and to such facility. Software which is licensed for use on hardware not offered by Bay Networks is not subject to restricted use on any Equipment, however, unless otherwise specified on the Documentation, each licensed copy of such Software may only be installed on one hardware item at any time.
2. Licensee may use the Software with backup Equipment only if the Equipment with which or for which it was acquired is inoperative.
3. Licensee may make a single copy of the Software (but not firmware) for safekeeping (archives) or backup purposes.
4. Licensee may modify Software (but not firmware), or combine it with other software, subject to the provision that those portions of the resulting software which incorporate Software are subject to the restrictions of this license. Licensee shall not make the resulting software available for use by any third party.
5. Neither title nor ownership to Software passes to licensee.
6. Licensee shall not provide, or otherwise make available, any Software, in whole or in part, in any form, to any third party. Third parties do not include consultants, subcontractors, or agents of licensee who have licensee's permission to use the Software at licensee's facility, and who have agreed in writing to use the Software only in accordance with the restrictions of this license.
7. Third-party owners from whom Bay Networks has acquired license rights to software that is incorporated into Bay Networks products shall have the right to enforce the provisions of this license against licensee.
8. Licensee shall not remove or obscure any copyright, patent, trademark, trade secret, or similar intellectual property or restricted rights notice within or affixed to any Software and shall reproduce and affix such notice on any backup copy of Software or copies of software resulting from modification or combination performed by licensee as permitted by this license.

9. Licensee shall not reverse assemble, reverse compile, or in any way reverse engineer the Software. [Note: For licensees in the European Community, the Software Directive dated 14 May 1991 (as may be amended from time to time) shall apply for interoperability purposes. Licensee must notify Bay Networks in writing of any such intended examination of the Software and Bay Networks may provide review and assistance.]
10. Notwithstanding any foregoing terms to the contrary, if licensee licenses the Bay Networks product "Site Manager," licensee may duplicate and install the Site Manager product as specified in the Documentation. This right is granted solely as necessary for use of Site Manager on hardware installed with licensee's network.
11. This license will automatically terminate upon improper handling of Software, such as by disclosure, or Bay Networks may terminate this license by written notice to licensee if licensee fails to comply with any of the material provisions of this license and fails to cure such failure within thirty (30) days after the receipt of written notice from Bay Networks. Upon termination of this license, licensee shall discontinue all use of the Software and return the Software and Documentation, including all copies, to Bay Networks.
12. Licensee's obligations under this license shall survive expiration or termination of this license.

Contents

About This Guide

Conventions xvi
Acronyms xvi
Ordering Bay Networks Publications xvi

Technical Support and Online Services

Bay Networks Customer Service xviii
Bay Networks Information Services xix
World Wide Web xix
Customer Service FTP xix
Support Source CD xx
CompuServe xx
InfoFACTS xxi
How to Get Help xxi

Chapter 1
Preparing for Installation

Choosing a Slot 1-1
Removing a Link Module 1-3
Configuring Jumper Settings 1-5

Chapter 2
Installing the Link Module

Inserting the Link Module 2-1
Connecting Cables 2-2

Chapter 3
Checking Status Indicators

Appendix A
Cabling Requirements

Appendix B
Requirements for European Operation

Installation Requirements B-1
Power Requirements B-1
Clearances and Creepage Distances B-2
European Safety Status B-4

Figures

Figure 1-1. Link Module Slots in a BLN Platform 1-2
Figure 1-2. Link Module Slots in a BLN-2 Platform 1-2
Figure 1-3. Link Module Slots in a BCN Platform 1-3
Figure 1-4. Jumpers on the Quad Sync Link Module 1-5
Figure 2-1. Link Module Captive Screws (BCN Example) 2-2
Figure 3-1. Sync LEDs 3-2
Figure A-1. 50-Pin to V.28 Standard Cable (Order No. AA0018023) A-1
Figure A-2. 44-Pin to V.28 Interface Cable (Order No. 7837) A-3
Figure A-3. Sync Adapter Cable (Order No. 7947) A-4
Figure A-4. 50-Pin to V.35 Standard Cable (Order No. 7932) A-6
Figure A-5. 44-Pin to V.35 Interface Cable (Order No. 7220) A-8

Tables

Table 1-1. Quad Sync Link Module Jumper Settings 1-6
Table 3-1. Functions of the Sync LEDs 3-2
Table A-1. 50-Pin to V.28 Standard Cable (Order No. AA0018023) Pin Assignments A-2
Table A-2. 44-Pin to V.28 Interface Cable (Order No. 7837) Pin Assignments A-3
Table A-3. Sync Adapter Cable (Order No. 7947) Pin Assignments A-4
Table A-4. 50-Pin to V.35 Standard Cable (Order No. 7932) Pin Assignments A-7
Table A-5. 44-Pin to V.35 Interface Cable (Order No. 7220) Pin Assignments A-8
Table A-6. 50-Pin to X.21 Interface Cable (Order No. 7936) Pin Assignments A-10
Table A-7. 15-Pin to X.21 Interface Cable (Order No. 7221) Pin Assignments A-11
Table A-8. 44-Pin to X.21 Interface Cable (Order No. 7224) Pin Assignments A-12
Table B-1. Link Module Power Requirements B-1
Table B-2. Link Module Clearances and Creepage Distances B-2
Table B-3. Octal Sync Safety Status (Order No. 5008) B-4
Table B-4. Quad Sync Safety Status (Order No. 5280) B-4

About This Guide

Read this guide if you are responsible for installing a Bay Networks™ Quad or Octal Sync link module in these Backbone Node (BN®) platforms:

- Backbone Link Node (BLN®)
- Backbone Link Node-2 (BLN-2)
- Backbone Concentrator Node (BCN®)

This guide describes how to

- Prepare for installation and configure the link module jumpers, if necessary
- Install the link module
- Interpret the LEDs on the link module

Appendix A describes cabline requirements and Appendix B, European operating standards.

Note: Experienced network operators can safely perform the user-serviceable procedures described in this book; however, only authorized Bay Networks service technicians can perform other maintenance procedures not described in this book.

Conventions

bold text	Indicates text that you need to enter and command names in text. Example: Use the **dinfo** command.
italic text	Indicates variable values in command syntax descriptions, new terms, file and directory names, and book titles.
quotation marks (“ ”)	Indicate the title of a chapter or section within a book.

Acronyms

ILI	Intelligent Link Interface
LED	light-emitting diode
RLSD	Receive Line Signal Detect
SELV	safety extra-low voltage
TNV	telecommunications network voltage

Ordering Bay Networks Publications

To purchase additional copies of this document or other Bay Networks publications, order by part number from the Bay Networks Press™ at the following telephone or fax numbers:

- Telephone - U.S./Canada 1-888-4BAYPRESS
- Telephone - International 1-510-490-4752
- Fax 1-510-498-2609

You can also use these numbers to request a free catalog of Bay Networks Press product publications.

Technical Support and Online Services

To ensure comprehensive network support to our customers and partners worldwide, Bay Networks Customer Service has Technical Response Centers in key locations around the globe:

- Billerica, Massachusetts
- Santa Clara, California
- Sydney, Australia
- Tokyo, Japan
- Valbonne, France

The Technical Response Centers are connected via a redundant Frame Relay Network to a Common Problem Resolution system, enabling them to transmit and share information, and to provide live, around-the-clock support 365 days a year.

Bay Networks Information Services complement the Bay Networks Service program portfolio by giving customers and partners access to the most current technical and support information through a choice of access/retrieval means. These include the World Wide Web, CompuServe, Support Source CD, Customer Support FTP, and InfoFACTS document fax service.

Bay Networks Customer Service

If you purchased your Bay Networks product from a distributor or authorized reseller, contact that distributor's or reseller's technical support staff for assistance with installation, configuration, troubleshooting, or integration issues.

Customers can also purchase direct support from Bay Networks through a variety of service programs. As part of our PhonePlus™ program, Bay Networks Service sets the industry standard, with 24-hour, 7-days-a-week telephone support available worldwide at no extra cost. Our complete range of contract and noncontract services also includes equipment staging and integration, installation support, on-site services, and replacement parts delivery -- within approximately 4 hours.

To purchase any of the Bay Networks support programs, or if you have questions on program features, use the following numbers:

Region	Telephone Number	Fax Number
United States and Canada	1-800-2LANWAN; enter Express Routing Code (ERC) 290 when prompted (508) 436-8880 (direct)	(508) 670-8766
Europe	(33) 92-968-300	(33) 92-968-301
Asia/Pacific Region	(612) 9927-8800	(612) 9927-8811
Latin America	(407) 997-1713	(407) 997-1714

In addition, you can receive information on support programs from your local Bay Networks field sales office, or purchase Bay Networks support directly from your authorized partner.

Bay Networks Information Services

Bay Networks Information Services provide up-to-date support information as a first-line resource for network administration, expansion, and maintenance. This information is available from a variety of sources.

World Wide Web

The Bay Networks Customer Support Web Server offers a diverse library of technical documents, software agents, and other important technical information to Bay Networks customers and partners.

A special benefit for contracted customers and resellers is the ability to access the Web Server to perform Case Management. This feature enables your support staff to interact directly with the network experts in our worldwide Technical Response Centers. A registered contact with a valid Site ID can

- View a listing of support cases and determine the current status of any open case. Case history data includes severity designation, and telephone, e-mail, or other logs associated with the case.
- Customize the listing of cases according to a variety of criteria, including date, severity, status, and case ID.
- Log notes to existing open cases.
- Create new cases for rapid, efficient handling of noncritical network situations.
- Communicate directly via e-mail with the specific technical resources assigned to your case.

The Bay Networks URL is *http://www.baynetworks.com*. Customer Service is a menu item on that home page.

Customer Service FTP

Accessible via URL *ftp://support.baynetworks.com* (134.177.3.26), this site combines and organizes support files and documentation from across the Bay Networks product suite, including switching products from our Centillion™ and Xylogics® business units. Central management and sponsorship of this FTP site lets you quickly locate information on any of your Bay Networks products.

Support Source CD

This CD-ROM -- sent quarterly to all contracted customers -- is a complete Bay Networks Service troubleshooting knowledge database with an intelligent text search engine.

The Support Source CD contains extracts from our problem-tracking database; information from the Bay Networks Forum on CompuServe; comprehensive technical documentation, such as Customer Support Bulletins, Release Notes, software patches and fixes; and complete information on all Bay Networks Service programs.

You can run a single version on Macintosh Windows 3.1, Windows 95, Windows NT, DOS, or UNIX computing platforms. A Web links feature enables you to go directly from the CD to various Bay Networks Web pages.

CompuServe

For assistance with noncritical network support issues, Bay Networks Information Services maintain an active forum on CompuServe, a global bulletin-board system. This forum provides file services, technology conferences, and a message section to get assistance from other users.

The message section is monitored by Bay Networks engineers, who provide assistance wherever possible. Customers and resellers holding Bay Networks service contracts also have access to special libraries for advanced levels of support documentation and software. To take advantage of CompuServe's recently enhanced menu options, the Bay Networks Forum has been re-engineered to allow links to our Web sites and FTP sites.

We recommend the use of CompuServe Information Manager software to access these Bay Networks Information Services resources. To open an account and receive a local dial-up number in the United States, call CompuServe at 1-800-524-3388. Outside the United States, call 1-614-529-1349, or your nearest CompuServe office. Ask for Representative No. 591. When you are on line with your CompuServe account, you can reach us with the command **GO BAYNET**.

InfoFACTS

InfoFACTS is the Bay Networks free 24-hour fax-on-demand service. This automated system has libraries of technical and product documents designed to help you manage and troubleshoot your Bay Networks products. The system responds to a fax from the caller or to a third party within minutes of being accessed.

To use InfoFACTS in the United States or Canada, call toll-free 1-800-786-3228. Outside North America, toll calls can be made to 1-408-764-1002. In Europe, toll-free numbers are also available for contacting both InfoFACTS and CompuServe. Please check our Web page for the listing in your country.

How to Get Help

Use the following numbers to reach your Bay Networks Technical Response Center:

Technical Response Center	Telephone Number	Fax Number
Billerica, MA	1-800-2LANWAN	(508) 670-8765
Santa Clara, CA	1-800-2LANWAN	(408) 764-1188
Valbonne, France	(33) 92-968-968	(33) 92-966-998
Sydney, Australia	(612) 9927-8800	(612) 9927-8811
Tokyo, Japan	(81) 3-5402-0180	(81) 3-5402-0173

Chapter 1
Preparing for Installation

Note: In this guide, the term Sync link module includes the Quad Sync and Octal Sync link modules, unless referring to a specific model.

Depending on your configuration, complete these preliminary tasks as needed to install the link module:

- Choose a slot
- Remove a link module
- Configure jumper settings

Choosing a Slot

You can install the link module in

- Slots 2 through 5 in the BLN platform (Figure 1-1)
- Slots 2 through 5 in the BLN-2 platform (Figure 1-2)
- Slots 1 through 6 and Slots 8 through 14 in the BCN platform (Figure 1-3)



Figure 1-1. Link Module Slots in a BLN Platform



Figure 1-2. Link Module Slots in a BLN-2 Platform



Figure 1-3. Link Module Slots in a BCN Platform

Removing a Link Module

If there are no empty slots in your BN platform, you must remove a link module to install the Sync link module. When replacing a configured link module, you must delete all configured circuits (ports) on the slot so the BN platform software can properly configure the new link module.

Refer to *Configuring Routers* if you use router software or *Administration Guide* if you use BayStream software for instructions on editing a configuration file and deleting circuits.

The Backbone Node hot-swap feature allows you to remove or replace a link module with the chassis power on or off.

Danger: Do not remove more than two adjacent modules with the power on.

When you remove a link module with the power on, the services that slot provides become disrupted. After the slot fails to receive packets, the other link modules in the chassis resynchronize their routing tables and continue uninterrupted.

The procedure for removing a link module is the same for the BLN, BLN-2, and BCN platforms:

1. **Disconnect any exterior cables from the link module.**
2. **Attach an antistatic wrist strap.**

   BN platforms and link modules ship with an antistatic wrist strap. You must wear one of these straps when accessing components on BN platforms. The antistatic wrist strap directs the discharge of static electricity from your body to the chassis, thereby avoiding discharge and possible damage to sensitive electronic components.

Caution: Electrostatic discharge can damage hardware. Always use the antistatic wrist strap when handling any component on your BN platform.

3. **Loosen the captive screw on each end of the module.**
4. **Grasp the sides of the module and pull it out of the slot.**
5. **Place the module in an antistatic protective bag.**

Configuring Jumper Settings

The Quad Sync link module (Order No. 5280) contains user-configurable jumper settings.

Note: The Octal Sync link module does not contain user-configurable jumpers or switches. Also, depending on the model, your Octal Sync link module may have a hardware compression daughterboard. This daughterboard does not contain user-configurable jumpers or switches.

Figure 1-4 shows only the user-configurable jumpers on the Quad Sync link module; changing the settings of any other jumpers on the link module can jeopardize module functioning.



Figure 1-4. Jumpers on the Quad Sync Link Module

Before installing the Quad Sync link module, refer to Table 1-1 to ensure that the user-configurable jumper settings on the link module match your configuration.

Table 1-1. Quad Sync Link Module Jumper Settings

Option	Setting	Jumper
Interface voltage	±12 for RS-232, V.28, V.35	
Com 1	Unbalanced signal for RS-232 and V.28*	
	Balanced signal for X.21†	
	Balanced signal for RS-422†	
Com 2	Unbalanced signal for RS-232 and V.28*	
	Balanced signal for X.21†	
	Balanced signal for RS-422†	

(continued)

Table 1-1. Quad Sync Link Module Jumper Settings *(continued)*

Option	Setting	Jumper
Com 3	Unbalanced signal for RS-232 and V.28*	
	Balanced signal for X.21†	
	Balanced signal for RS-422†	
Com 4	Unbalanced signal for RS-232 and V.28*	
	Balanced signal for X.21†	
	Balanced signal for RS-422†	

(continued)

Table 1-1. Quad Sync Link Module Jumper Settings *(continued)*

Option	Setting	Jumper
Daughterboard **Note**: Each J-to-S row resides in a separate location on the module	Daughterboard not installed	
	Daughterboard installed	

*. When configuring for V.35, place the S10, S11, S12, and S13 jumpers (A through E) in the unbalanced position to support V.35/V.28 control signals.

†. These jumpers determine the output voltage levels on the unbalanced driver devices. We recommend that you leave the jumpers in the ±12V position for correct unbalanced operation.

Chapter 2
Installing the Link Module

Complete the steps in this chapter to install the Sync link module in your BLN, BLN-2, or BCN platform.

Inserting the Link Module

Install the link module in the BLN, BLN-2, or BCN platform as follows:

1. **Attach an antistatic wrist strap.**

   BN platforms and link modules ship with an antistatic wrist strap. You must wear one of these straps whenever you access components in a platform.

   The antistatic wrist strap directs the discharge of static electricity from your body to the chassis, thereby avoiding discharge and possible damage to sensitive electronic components.

Caution: Electrostatic discharge can damage hardware. Always use the antistatic wrist strap when handling any router components.

2. **Using the slot card guides, slide the module into the appropriate slot until the module's connector panel touches the BN platform's back panel.**

   Refer to Figure 1-1 (BLN), 1-2 (BLN-2), or 1-3 (BCN) in Chapter 1 for slot locations.

3. **Secure the captive screw on each end of the module (Figure 2-1).**

   Figure 2-1 shows the captive screws on a Quad Sync link module; these screws are the same on all link modules.



Figure 2-1. Link Module Captive Screws (BCN Example)

4. **Once you are done accessing the interior of the chassis, remove the antistatic wrist strap.**

Connecting Cables

Connect the necessary cables to the link module ports.

Refer to the cable guide for information about the cables Bay Networks supports for link modules.

Chapter 3
Checking Status Indicators

This chapter describes the status indicator lights (LEDs) on the Sync link modules. Use the LEDs to verify that the link module is operating after installation.

Note: We recommend that you issue the **diags** command to the associated slot, using the Bay Networks Technician Interface, immediately after you insert a link module. (Refer to *Using Technician Interface Software* if you use router software or *Troubleshooting and Testing* if you use BayStream software.) Otherwise, the link module FAIL LED will remain lit, indicating that diagnostics have not run on the Intelligent Link Interface (ILI). However, even if you do not issue the **diags** command, the link module initializes and becomes operational as long as the board functions properly and contains the correct interface configurations.

Figure 3-1 shows the Sync LEDs, while Table 3-1 describes their functions.



SYN0003A

Figure 3-1. Sync LEDs

Table 3-1. Functions of the Sync LEDs

LED	Function
RLSD1 (Receive Line Signal Detect) through RLSD8	Indicates Carrier Detect is present on the respective port.
DIAG 1 and 2 (Octal Sync only)	Reserved for future use.
FAIL	Indicates one of the following conditions: • Diagnostic testing is in progress. Diagnostic testing occurs when you cold-start the module. You cold-start the module when you cycle power, issue the **diags** command from the Technician Interface, or hot-swap the link module. This LED blinks three times and turns off when diagnostic testing terminates successfully. • Power-up diagnostic testing failed and the link module is waiting for an automatic attempt to reinitiate diagnostic testing. If the FAIL LED turns on again, call the Bay Networks Technical Response Center. • A catastrophic failure from a hardware problem on the link module occurred and the link module is waiting for an automatic attempt to reinitiate diagnostic testing. If the FAIL LED turns on again, call the Bay Networks Technical Response Center.

Appendix A
Cabling Requirements

This appendix provides technical information about cabling requirements for the Octal Sync link module (Order No. 5008).

To support V.28, you can use the V.28-compliant, straight-through cable, Order No. AA0018023. Alternatively, you can use the Order No. 7837 cable combined with an adapter cable, Order No. 7947.

To support V.35, you can use the V.35-compliant, straight-through cable, Order No. 7932. Alternatively, you can use the Order No. 7220 cable combined with an adapter cable, Order No. 7947.

To support X.21, you can use the X.21-compliant, straight-through cable, Order No. 7936. Alternatively you can use Order No. 7221, or Order No. 7224 cable, combined with an adapter cable, Order No. 7947.

Refer to the following tables and illustrations for cabling information.



Figure A-1. 50-Pin to V.28 Standard Cable (Order No. AA0018023)

Table A-1. 50-Pin to V.28 Standard Cable (Order No. AA0018023) Pin Assignments

Bay Networks Termination		**Remote Termination**	
Pin	**Signal**	**Pin**	**Signal**
1	Frame Ground	1	Frame Ground
2	Send Data+	2	Send Data
3	Receive Data+	3	Receive Data
4	Request to Send+	4	Request to Send
5	Clear to Send+	5	Clear to Send
6	Data Set Ready+	6	Data Set Ready
8	Data Terminal Ready+	20	Data Terminal Ready
9	Data Carrier Detect+	8	Data Carrier Detect
10	Send Timing+	15	Send Timing
11	Receive Timing+	17	Receive Timing
12	Xmitter Signal Element Timing+	24	Xmitter Signal Element Timing
7	Signal Ground	7	Signal Ground
Local Wire Connections			
Pin 7 -> 30 -> 31->34			
Pin 13 -> 38			
Pin 14 -> 39			



Figure A-2. 44-Pin to V.28 Interface Cable (Order No. 7837)

Table A-2. 44-Pin to V.28 Interface Cable (Order No. 7837) Pin Assignments

Bay Networks Termination		Remote Termination	
Pin	**Signal**	**Pin**	**Signal**
1	Frame Ground	1	Frame Ground
2	Send Data+	2	Send Data
3	Receive Data+	3	Receive Data
4	Request to Send+	4	Request to Send
5	Clear to Send+	5	Clear to Send
6	Data Set Ready+	6	Data Set Ready
8	Data Terminal Ready+	20	Data Terminal Ready
9	Data Carrier Detect+	8	Data Carrier Detect
10	Send Timing+	15	Send Timing
11	Receive Timing+	17	Receive Timing
12	Xmitter Signal Element Timing+	24	Xmitter Signal Element Timing
7	Signal Ground	7	Signal Ground

(continued)

Table A-2. 44-Pin to V.28 Interface Cable (Order No. 7837) Pin Assignments *(continued)*

Bay Networks Termination	Remote Termination
Local Wire Connections	
Pin 7 -> 19 -> 20->23	
Pin 13 -> 28	
Pin 14 -> 29	



Figure A-3. Sync Adapter Cable (Order No. 7947)

Table A-3. Sync Adapter Cable (Order No. 7947) Pin Assignments

Run #	44-Pin	50-Pin	Twist with Run #	Signal
1	1	1	No Twist	FGND
2	2	2	3	SD+
3	16	27	2	SD-
4	3	3	5	RD+
5	17	28	4	RD-
6	4	4	7	RTS+
7	18	29	6	RTS-
8	5	5	9	CTS+

(continued)

Table A-3. Sync Adapter Cable (Order No. 7947) Pin Assignments *(continued)*

Run #	44-Pin	50-Pin	Twist with Run #	Signal
9	19	30	8	CTS-
10	6	6	11	DSR+
11	20	31	10	DSR-
12	21	32	No Twist	Not Used
13	7	7	No Twist	SGND
14	8	8	15	DTR+
15	22	33	14	DTR-
16	9	9	17	DCD+
17	23	34	16	DCD-
18	10	10	19	ST+
19	24	35	18	ST-
20	11	11	21	RT+
21	25	36	20	RT-
22	12	12	23	TT+
23	26	37	22	TT-
24	27	50	No Twist	Not Used
25	13	13	No Twist	RTIN#
26	28	38	No Twist	RTIN#B
27	14	14	No Twist	CTS#
28	29	39	No Twist	CTSIN#
29	15	15	No Twist	RTS#
30	30	40	No Twist	ST#
31	31	16	32	VST-
32	32	41	31	VST+
33	33	17	34	VRT-
34	34	42	33	VRT+
35	35	18	36	VRD-
36	37	43	35	VRD+
37	36	19	38	VSD-

(continued)

Table A-3. Sync Adapter Cable (Order No. 7947) Pin Assignments *(continued)*

Run #	44-Pin	50-Pin	Twist with Run #	Signal
38	38	44	37	VSD+
39	39	20	40	VTT-
40	40	45	39	VTT+
41	41	46	No Twist	UNBE
42	42	47	No Twist	V35D
43	43	48	44	GND
44	44	49	43	SNDC



Figure A-4. 50-Pin to V.35 Standard Cable (Order No. 7932)

Table A-4. 50-Pin to V.35 Standard Cable (Order No. 7932) Pin Assignments

Pair Number	Bay Networks Termination		Remote Termination	
	Pin	**Signal**	**Pin**	**Signal**
1	44	VSD+	P	Send Data A
1	19	VSD-	S	Send Data B
2	42	VRT+	V	Receive Timing A
2	17	VRT-	X	Receive Timing B
3	41	VST+	Y	Send Timing A
3	16	VST-	AA	Send Timing B
4	43	VRD+	R	Receive Data A
4	18	VRD-	T	Receive Data B
5	6	DSR+	E	Data Set Ready
5	8	DTR+	H	Data Terminal Ready
6	4	RTS+	C	Request to Send
6	5	CTS+	D	Clear to Send
7	45	VTT+	U	Terminal Timing A
7	20	VTT-	W	Terminal Timing B
8	1	FGND	A	Frame Ground
9	9	DCD+	F	Data Carrier Detect
9	30	SGND	B	Signal Ground
Local Wire Connections				
	Pin 30 -> 31 -> 7->34			
	Pin 46 -> 47-> 48			
	Pin 13 -> 38			
	Pin 14 -> 39			



Figure A-5. 44-Pin to V.35 Interface Cable (Order No. 7220)

Table A-5. 44-Pin to V.35 Interface Cable (Order No. 7220) Pin Assignments

Bay Networks Termination		Remote Termination	
Pin	**Signal**	**Pin**	**Signal**
38	VSD+	P	Send Data A
36	VSD-	S	Send Data B
34	VRT+	V	Receive Timing A
33	VRT-	X	Receive Timing B
32	VST+	Y	Send Timing A
31	VST-	AA	Send Timing B
37	VRD+	R	Receive Data A
35	VRD-	T	Receive Data B
6	Data Set Ready+	E	Data Set Ready
8	Data Terminal Ready+	H	Data Terminal Ready
4	Request to Send+	C	Request to Send
5	Clear to Send+	D	Clear to Send
40	VTT+	U	Terminal Timing A

(continued)

Table A-5. 44-Pin to V.35 Interface Cable (Order No. 7220) Pin Assignments *(continued)*

Bay Networks Termination		Remote Termination	
39	VTT-	W	Terminal Timing B
1	Frame Ground	A	Frame Ground
9	Data Carrier Detect+	F	Data Carrier Detect
19	Signal Ground	B	Signal Ground
Local Wire Connections			
Pin 19 -> 20 -> 23 -> 7			
Pin 41 -> 42 -> 43			
Pin 13 -> 28			
Pin 14 -> 29			



Figure A-6. 50-Pin to X.21 Interface Cable (Order No. 7936)

Table A-6. 50-Pin to X.21 Interface Cable (Order No. 7936) Pin Assignments

Bay Networks Termination		Remote Termination	
Signal	**Pin # to Pin #**		**Signal**
Send Data+	2	2	Transmitted Data A
Send Data-	27	9	Transmitted Data B
Request to Send+	4	3	Control A
Request to Send-	29	10	Control B
Receive Data+	3	4	Receive Data A
Receive Data-	28	11	Receive Data B
Data Carrier Detect+	9	5	Indication A
Data Carrier Detect-	34	12	Indication B
Timing+	10	6	Timing A
Timing-	35	13	Timing B
Frame Ground	1	1	Frame Ground
Signal Ground	7	8	Signal Ground
Internal Connections			
Pin 46 > 48 (GRD)			
Pin 38 > 40			
Pin 14 > 15			



15-position D-sub plug with locking posts (ground shield connected to backshell)

15-position D-sub plug with M-3 jack screws (ground shield connected to backshell)

CAB0044A

Figure A-7. 15-Pin to X.21 Interface Cable (Order No. 7221)

Table A-7. 15-Pin to X.21 Interface Cable (Order No. 7221) Pin Assignments

Bay Networks Termination		Remote Termination	
Signal	**Pin # to Pin #**		**Signal**
Ground	1	1	Ground
Send Data+	2	2	Transmitted Data A
Send Data-	3	9	Transmitted Data B
Request to Send+	6	3	Control A
Request to Send-	15	10	Control B
Receive Data+	14	4	Receive Data A
Receive Data-	13	11	Receive Data B
Data Carrier Detect+	10	5	Indication A
Data Carrier Detect-	9	12	Indication B
Send Timing+	4	6	Timing A
Send Timing-	5	13	Timing B



Figure A-8. 44-Pin to X.21 Interface Cable (Order No. 7224)

Table A-8. 44-Pin to X.21 Interface Cable (Order No. 7224) Pin Assignments

Bay Networks Termination		**Remote Termination**	
Pin	**Signal**	**Pin**	**Signal**
2	Send Data+	2	Send Data A
16	Send Data-	9	Send Data B
4	Request to Send+	3	Control A
18	Request to Send-	10	Control B
3	Receive Data+	4	Receive Data A
17	Receive Data-	11	Receive Data B
9	Data Carrier Detect+	5	Indication A
23	Data Carrier Detect-	12	Indication B
10	Send Timing+	6	Timing A
24	Send Timing-	13	Timing B
7	Signal Ground	8	Signal Ground
1	Frame Ground	1	Frame Ground
Local Wire Connections			
Pin 41 -> 43			
Pin 28 -> 30			
Pin 14 -> 15			

Appendix B
Requirements for European Operation

This appendix provides technical specifications and notes about operating the following link modules in Europe:

- Quad Sync (Order No. 5280, Part No. 102285)
- Octal Sync (Order No. 5008, Part No. 109871)

Installation Requirements

The link modules are approved only for installation in a host, and with host attachments, which are either type approved for such apparatus or, if supplied after March 1, 1989, are marked with or supplied with a statement that the host is supplied under the terms of General Approval No. NS/G/1234/J/100003.

Installation of the link modules in a BLN, BLN-2, or BCN platform will satisfy the conditions stated in this appendix. The BLN, BLN-2, and BCN platforms are supplied under the terms of General Approval NS/G/1234/J/100003.

Power Requirements

The link modules are powered from the host chassis and have the power requirements shown in Table B-1.

Table B-1. Link Module Power Requirements

Voltage	Amperage
+5 V	5 A
+12 V	0.75 A
-12 V	0.75 A

The power drawn from the host chassis, combined with the power needs of any other link modules and accessories, must be within the power rating of the host chassis.

You must install the link modules so as not to impair the integrity of the network protection from hazardous voltages used or generated internally by the host chassis.

Clearances and Creepage Distances

You must maintain the clearances and creepage distances (shown as X and Y, respectively, in Table B-2 and Figure B-1) between the link module and

- The host chassis in which it is installed
- Any adjacent link modules installed in the host chassis

The exception to this rule is the edge connector, which is located in the host chassis backplane, where no minimum distance applies.

Table B-2. Link Module Clearances and Creepage Distances

Clearance (X)	Creepage (Y)	Voltage Used or Generated by Other Parts of the Host or Expansion Card
2.0 mm	2.4 (3.8) mm	Up to 50 V rms or V dc
2.6 mm	3.0 (4.8) mm	Up to 125 V rms or V dc
4.0 mm	5.0 (8.0) mm	Up to 250 V rms or V dc
4.0 mm	6.4 (10.0) mm	Up to 300 V rms or V dc

The creepage distances apply to the normal office environment. When the local environment within the host chassis is subject to conductive pollution or dry nonconductive pollution that could become conductive due to condensation, the creepage distances shown in parentheses in Table B-2 will apply.

The clearance and creepage distance between adjacent points should be checked as follows (Figure B-1):

- The clearance distance (X) is the shortest distance between two points measured through the air.
- The creepage distance (Y) is the shortest distance between two points measured across a surface.



Figure B-1. Link Module Clearances and Creepage Distances

You should obtain advice from a competent telecommunications safety engineer if in doubt.

Failure to install a link module according to these instructions will invalidate the Approval.

European Safety Status

The tables in this section detail the safety status of each product as defined by European Standard EN41003.

Octal Sync Safety Status (Order No. 5008)

Table B-3 lists the safety status of interconnection points to the connection of other equipment.

Table B-3. Octal Sync Safety Status (Order No. 5008)

Port Location	Port Description	Type of Circuit
Port 1 - 8	V.28, X.21, V.35	Telecommunications network voltage(TNV)
J30	Host Port	Safety extra-low voltage (SELV)
J2	Host Power	SELV

Quad Sync Safety Status (Order No. 5280)

Table B-4 lists the safety status of interconnection points to the connection of other equipment.

Table B-4. Quad Sync Safety Status (Order No. 5280)

Port Location	Port Description	Type of Circuit
COMM1	V.28, X.21, V.35	TNV @ SELV levels
COMM2	V.28, X.21, V.35	TNV @ SELV levels
COMM3	V.28, X.21, V.35	TNV @ SELV levels
COMM4	V.28, X.21, V.35	TNV @ SELV levels
P3	Host Port	SELV
J5	Host Power	SELV